

RAINWATER FILTERS IN POLYETHELENE



RAINWATER PRE-FILTER WITH SIEVE BASKET

- Rainwater filter with sieve basket.
- The rainwater is flowing through the sieve basket and leaves the dirt in the sieve
- Has to be cleaned regularly
- To install in front of the tank.



SELF-CLEANING PRE-FILTER WITH STAINLESS STEEL FILTER TUBE

- Rainwater filter with stainless steel filter tube
- Very high return (95%)
- Very small decline (14 cm)
- For surface up to 400 m²
- To install in front of the tank, or in the riser.

SELF-CLEANING PRE-FILTER WITH CASSETTE


- Rainwater filter with cassette
- Filtering in 2 stages
- Adjustable riser included
- For surface up to 400 m²
- To install in front of the tank

SELF-CLEANING COMPACT FILTER

- Rainwater flow– trough filter
- The filter has a partly self-cleaning operation
- Frequent cleaning is advised
- For surface up to 210 m²
- To install in the tank with a slow-flow

SELF-CLEANING BUILD-IN FILTER

- Build-in rainwater filter
- Available in 110, 160, 200 en 300 mm
- To install in the tank with a slow-flow
- Can be pre-installed in a small tank
- Also available with a one-way valve



Boralit NV

Nijverheidslaan 12, BE 9880 Aalter—Belgium—2017

Tel: +32 (0)9 375 11 11 Fax: +32 (0)9 375 22 22

E-mail: sales@boralit.be

www.boralit.com

BORALIT

plastic tank solutions